



**PROBLEM** 



**SOLUTION** 



In addition to the Aftermarket version for installation on straps already in service, the StrapPak™ is also available in a fully Assembled version. It can be ordered on any standard or stenciled two inch ratchet strap assembly with a variety of end fittings.

## **OPERATING INSTRUCTIONS**

**Operation of StrapPak™ to Secure Loose End of Strap Assembly** 

- 1. Secure cargo as per federal, state or provincial standards
- 2. Open ratchet to approximately 120° angle (Figure #1)
- 3. Starting with free end of strap fold over approximately 6" of material and continue folding excess web to create a flat loop as shown (Figure #2)
- 4. Insert flat loop of web material into open end of StrapPak™ as shown (Figure # 3)
- 5. Close the ratchet handle. Top of bag will remain secure when held in place by ratchet handle in fully closed position (Figure #4).

## **Notice:**

- Operator may use hook end facing either up or down depending on application
- StrapPak™ for use with 2" ratchet straps with 12" minimum fixed end web length



Figure #1



Figure #2



Figure #3



Figure #4

**DISTRIBUTOR:** 

